


Models 500 thru 509



Models 500 thru 509

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	747-1161A	Blade Control Handle	23.	748-0376C	Blade Adapter
2.	749-1092A	Upper Handle	24.	742-0642A	Blade 22"
3.	746-0957	Blade Control Cable - B&S 37.25" LG		742-0742A	Mulching Blade 22" (If Equipped)
	746-1130	Blade Control Cable - B&S 40" LG	25.	710-1044	Hex Cap Screw 3/8-24 x 1.5
	746-1091	Blade Control Cable - Tec 50" LG	26.	736-0524A	Blade Bell Support
4.	710-1205	Eye Bolt	27.	738-1172	Shoulder Screw 3/8 - 16 x .302
5.	720-0279	Wing Nut	28.	736-0741	Bell Washer .760 ID x 1.25 OD
6.	720-0284	Wing Nut	29.	734-1988	Front Wheel Assembly 7 x 1.8
7.	736-0451	Shoulder Washer .320 ID x .93 OD		734-1980	Front Wheel Assembly 7 x 2
8.	710-1174	Carriage Bolt 5/16-18 x 2.0	31.	720-0426	Height Adjuster Knob
9.	725-0157	Cable Tie	32.	732-1026	Front Spring Lever
10.	749-04037	Lower Handle	33.	747-0710	Hinge Pin
11.	731-0981A	Hub Caps (If Equipped)	34.	732-1014	Torsion Spring
12.	17098	Hinge Clip	35.	731-1035B	Chute Hinge
13.	731-2280	Trail Shield	36.	731-1034B	Side Discharge Chute Assembly
14.	682-3062A	Handle Bracket Assembly - RH	38.	710-0216	Hex Cap Screw 3/8-16 x .75
15.	682-3063A	Handle Bracket Assembly - LH	39.	741-0717	Thrust Bearing .688 ID x 1.938 OD
16.	736-3050	Flat Washer .406 ID x .812 OD	40.	682-0093	Rear Pivot Arm Assembly
17.	712-0431	Lock Nut 3/8 -16	41.	732-0984B	Rear Spring Lever
18.	710-0654A	Hex Washer Screw 3/8-16 x 1.0	42.	738-1127	Shoulder Screw 3/8 - 16 x .442
19.	687-02045	Deck Assembly 22"	43.	736-0182	Spring Washer
	687-02048	Deck Assembly 22" (No Sprigs)	44.	734-1864	Rear Wheel Assembly 14 x 1.8
20.	736-0270	Bell Washer .265 x .75		734-1861	Rear Wheel Assembly 14 x 2
21.	741-0751	Height Adjuster Bearing	46.	731-04197	Snap Mulching Plug (If Equipped)
22.	682-0113	Pivot Arm Assembly	47.	736-0105	Washer Spacer .401 ID x .870 OD
			48.	712-0130	Hex Lock Nut 3/8-16