


# 21" DELUXE CONVERTIBLE ROTARY MOWER

MODEL: A131-J

Grass Catcher Model: Included

Repl Bag: P/N 129023



## 21" DELUXE CONVERTIBLE ROTARY MOWER

MODEL: A131-J

Grass Catcher Model: Included

Repl Bag: P/N 129023

Item No.	Part No.	Description	Item No.	Part No.	Description
1	457176	Bolt - 3/8-16 x 1-1/4 Gr. 5	44	156307	Shaft - Connecting
2	156232	Bolt - Blade	45	310052	Nut - Hex 1/4-20
3	311035	Lockwasher - Split 1/2	46	156844	Nut - Push 1/8
4	030528	Blade - 21	47	461665	Lockwasher - Internal Tooth 5/16
5	109256	Coupling - Blade	48	150201	Washer - Curved 5/16
6	150276	Key - Woodruff #6	49	109322	Guide - Lower Rope
7	715086	Locknut - Hex 3/8-16	50	151936	Bolt - Curved Head 5/16-18 x 2-1/4
8	156364	Bolt - Carriage 5/16-18 x 5/8	51	459131	Bolt - Hex 5/16-18 x 1
9	109207	Bracket - Axle	52	156331	Rivet - Nylon 3/16
10	024901	Axle Assembly - Front	53	156810	Rivet - Spec. Pop 3/16
11	151340	Locknut - Flange 5/16-18	54	109504	Support - Chute Opening
12	151613	Bolt - Hex Sems #10 - 32 x 3/8	55	156273	Washer - Flat #10
13	150060	Bolt - Wheel	56	001800	Decal - Catcher Warning
14	041426	Wheel	57	150318	Clamp - Cable
15	156257	Rivet - Pop 1/4 x 3/8	58	001206	Decal - Blade Rotation Warning
16	091215	Lever - Height Adjustment	59	110397	Tie - Cable
17	111559	Tip - Plastic Lever	60	148411	Decal - Warning Oil Overfill
18	001818	Decal - Chute Warning	61	152074	Rope Stop
19	024844	Plate - Back	62	760074	Decal - Engine Control
20	112052	Cover - Deck	63	156422	Insert - Plastic 1/4
21	156265	Screw - Wing 1/4-20 x 3/4	64	715417	Washer - Flat 3/8 SAE
22	715300	Washer - Flat 1/4	65	152371	Guide - Upper Rope
23	156281	Nut - Speed 1/4	66	715037	Nut - Hex Keys 1/4-20
24	024802	Deck - Push 21	67	051466	Cable - Bail
25	024877	Baffle - Rear	68	451992	Nut - Flange Top Lock 3/8-16
26	024885	Baffle - Front	69	072405	Handle - Lower
27	024919	Axle Assembly - Rear	70	111997	Top - Catcher
28	156968	Bolt - Hex 5/16-18 x 1-1/4 Gr. 5	71	109298	Bail - Coated Black
29	024869	Bracket - Handle LH	72	072306	Handle - Upper w/Foam Grip
30	024851	Bracket - Handle RH	73	129015	Cover - Body Assembly - Chute
31	156349	Rivet - Pop 1/8 x 1/4	74	744284	Knob - Handle
32	715243	Rivet - Pop 3/16 x 1/8	75	672345	Cap - Hub
33	112136	Shield - Trailing	76	129023	Frame & Bag Assembly
34	152389	Rivet - 3/16 x 11/32	77	110064	Cap - Plastic Bolt
35	109496	Strip - Backing	78	024935	Support - Catcher
36	450437	Bolt - Hex 5/16-18 x 5/8 Gr. 5	79	156414	Bolt - Hex Flange 3/8 x 1
37	150623	Screw - Hex Slotted #10 x 5/8	80	153874	Bolt - Hex 1/4-20 x 2-1/4
38	112011	Screen - Large	81	051235	Control - Throttle
39	112029	Screen - Small	82	715185	Washer - Flat 5/16
40	111963	Clip - Handle	83	143115	Decal - Warning CPSC
41	134445	Seal - Door	84	715490	Locknut - 5/16-18
42	134452	Seal - Bag	85	715607	Washer - 3/8 Belleville
43	156299	Knob Catcher			

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only **Genuine Factory Replacement Parts (OEM)** that are specifically designed for the particular model that you are working with.
- Parts are right or left hand as viewed from the operator's position.
- Model specifications are subject to change without prior notice.
- **Do not operate** the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice.