


22" SIDE DISCHARGE HIGH-WHEEL ROTARY MOWER

MODEL: A2300-J

Grass Catcher Model: GC6AA P/N 161018

Repl. Bag: P/N 161158



22" SIDE DISCHARGE HIGH-WHEEL ROTARY MOWER

MODEL: A2300-J

Grass Catcher Model: GC6AA P/N 161018

Repl. Bag: P/N 161158

Index No.	Part No.	Description	Index No.	Part No.	Description
1	019780	Deck 22"	27	715417	Washer - 3/8 SAE Flat*
2	018101	Bracket - Wheel	28	715607	Washer - 3/8 Belleville
3	715508	Nut - 1/4-20 Hx Lock	29	133231	Adapter - Blade
4	112821	Shield - Plastic Trailing	30	106914	Clip - Trailing Shield
5	030049	Blade - 22" Flat	31	144063	Decal - C.P.S.C. Danger
6		Wheel Assemblies*	32	001206	Decal - Blade Warning
	040857	8" Plastic - White - Diamond - Nylon Bearing	33	715557	Decal - Starting Instructions
	040865	8" Plastic - White - Diamond - Roller Bearing	34	150011	Bolt - 1/4-20 x 5/8 Carriage
	041848	8" Steel - White - Rib - Flange Bearing	35	457168	Bolt - 3/8-16 x 7/8 Hx Hd Thd Forming
7	040410	Wheel - 16 x 1.75	36	150060	Bolt - Front Wheel
8	052209	Cable - Engine/Blade Control	37	462093	Washer - 1/4" Flat
9	052217	Control - Throttle w/Cable	38	150201	Washer - 5/16 Curved
10	071563	Handle - Lower	39	150235	Wingnut - 5/16-18
11	071076	Handle - Upper	40	150276	Key - #6 Woodruff
	071084	Handle - Upper with Cushion Grips*	41	457499	Bolt - 1/4-20 x 1/2 Hx Hd Thd Forming
12	777862	Wheel Lever - Height Adjuster*	42	157552	Clamp - Cable
13	776500	Setting Lever - Height Adjuster*	43	150623	Screw - #10 x 5/8 Self-Tap
14	428664	Back Plate - Height Adjuster RH Front*	44	162024	Bolt - Blade
15	428714	Back Plate - Height Adjuster LH Front*	45	153650	Bolt - Shoulder Height Adjuster*
16	106336	Washer - Blade	46	458687	Bolt - #10-24 x 1/2 Hx Hd
17	100396	Bar - Stabilizer	47	715011	Pin - #3 Hitch
18	101519	Baffle - Deck	48	381442	Clamp - Tinnerman
19	103424	Spacer - Wheel Sleeve	49	151647	Bolt - 3/8-16 x 4 Hx Hd
20	104687	Ball - Engine/Blade Control	50	151928	Bolt - 5/16-18 x 1-3/4 Curved Hd
21	393595	Chute Deflector Assembly	51	152074	Stop - Rope
21A	393613	Chute Deflector Assembly	52	451492	Nut - 3/8-16 Top Lock Flange
22	110379	Tie - Cable	53	452318	Nut - #10-24 Nylon Insert
23	715326	Bolt - 3/8-16 x 1 Hx Hd	54	715045	Bolt - 1/4-20 x 3/4 Hx Hd
24	111559	Plastic Tip - Setting Lever*	55	152371	Guide - Rope
25	107086	Bracket - RH Handle	56	715037	Nut - 1/4-20 Keps
26	107094	Bracket - LH Handle	57	153874	Bolt - 1/4-20 x 2-1/4 Hx Hd Gr 2

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only **Genuine Factory Replacement Parts (OEM)** that are specifically designed for the particular model that you are working with.
- Parts are right or left hand as viewed from the operator's position.
- Model specifications are subject to change without prior notice.
- **Do not operate** the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice.