


20"/22" SIDE DISCHARGE ROTARY MOWER

MODEL: C223-J

O2031-J

Grass Catcher Model: GC6AA P/N 161018

Repl. Bag: P/N 161158



Mowers Without Height Adjusters

**20"/22" SIDE DISCHARGE ROTARY MOWER
MODEL: C223-J**

O2031-J

Grass Catcher Model: GC6AA P/N 161018

Repl. Bag: P/N 161158

Index No.	Part No.	Description	Index No.	Part No.	Description
1	019042	Deck 20"	20	009415	Decal-Blade Warning
	019778	Deck 22"	21	144899	Decal-Starting Instructions
2	030031	Blade-20" Flat	22	776500	Setting Lever - Height Adjuster*
	030049	Blade-22" Flat	23	150060	Wheel Bolt w/Hgt. Adj.*
3		Wheel Assembly*	24	150201	Washer-Curved 5/16
	041012	6" Plastic - White - Diamond	25	150235	Wingnut 5/16-18
	041533	6½" Plastic - White - Diamond	26	150276	Woodruff Key #6
	040246	7" Plastic-White-Diamond	27	150318	Cable Clamp
	041525	7" Plastic-White-Diamond	28	150623	Screw-Sheet Metal #10 x 5/8
	041046	7" Steel - White-Rib-Flange Bearing	29	150730	Wheel Bolt w/o Hgt. Adj.*
	040857	8" Plastic-White-Diamond	30	162024	Bolt-Blade
	040865	8" Plastic-White-Diamond-Roller Bearing	31	777862	Wheel Lever - Height Adjuster*
	041111	8" Steel-White-Rib-Flange Bearing	32	151928	Bolt-Curved Head 5/16-18 x 1 3/4
	042432	8" Plastic-White-Diamond	33	152074	Rope Stop
4	051219	Control-Throttle w/Cable	34	152371	Rope Guide
5	052142	Cable-Engine Blade Control	35	153650	Shoulder Bolt-Hgt. Adj.*
6	071563	Handle-Lower	36	428664	Back Plate-Height Adjuster R.H. Front L.H. Rear*
7	071076	Handle-Upper	37	428714	Back Plate-Height Adjuster L.H. Front R.H. Rear*
	071084	Handle-Upper Vinyl Grip	38	452318	Nut-#10-24 HX Nylon Insert
	072181	Handle-Upper Cushion Grip	39	457168	Bolt-3/8-16 x 7/8 Thread Forming
8	101519	Baffle 20/22" Rear or Front*	40	457499	Bolt-1/4-20 x 1/2 Thread Forming
9	104687	Bail-Engine/Blade Control	41	462093	Washer-Flat 1/4"*
	109470	Bail-Engine/Blade Control Vinyl Grip	42	458687	Bolt-Hex Head #10-24 x 1/2
10	106336	Washer-Blade Adapter	43	153874	Bolt-1/4-20 x 2 1/4 Hex Head
11	106914	Clip-Trailing Shield	44	715011	Hairpin Cotter
12	088369	Handle Bracket-Right Hand	45	715037	Nut-Keps 1/4-20
13	088377	Handle Bracket-Left Hand	46	715045	Bolt-Hex Head 1/4-20 x 3/4*
14	394619	Chute Deflector Assembly	47	451492	Locknut 3/8-16 Top TopLock Flange
15	110379	Cable Tie	48	715201	Bolt-Hex 3/8-16 x 3/4 w/o Hgt. Adj.
16	114405	Trailing Shield-20/22" w/o Hgt. Adj.	49	715607	Washer-Belleville
	114421	Trailing Shield-20/22" w/Hgt. Adj.	50	715417	Washer 3/8 SAE*
17	114462	Plastic Tip-Setting Lever*	51	715508	Locknut 1/4-20 Top
18	133231	Blade Adapter			
19	144063	Decal-Danger			

• INDICATES OPTIONAL EQUIPMENT

• INDICATES OPTIONAL EQUIPMENT

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only **Genuine Factory Replacement Parts (OEM)** that are specifically designed for the particular model that you are working with.
- Parts are right or left hand as viewed from the operator's position.
- Model specifications are subject to change without prior notice.
- **Do not operate** the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice.