

22" SIDE DISCHARGE HIGH-WHEEL ROTARY MOWER


MODEL: CEHW5-J

FUDH22-J

WDH-J

Grass Catcher Model: GC6AA P/N 161018

Repl. Bag: P/N 161158



**22" SIDE DISCHARGE HIGH-WHEEL ROTARY MOWER
MODEL: CEHW5-J
FUDH22-J
WDH-J**

Grass Catcher Model: GC6AA P/N 161018
Repl. Bag: P/N 161158

Index No.	Part No.	Description	Index No.	Part No.	Description
1	021931	Deck 22"	28	715607	Washer—3/8 Belleville
2	019117	Bracket—Wheel	29	126466	Adapter—Blade
3	152421	Washer—Spring	30	106914	Clip—Trailing Shield
4	114439	Shield—Plastic Trailing	31	144063	Decal—C.P.S.C. Danger
5	030049	Blade—22" Flat	32	001206	Decal—Blade Warning
6		Wheel Assemblies*	33	715557	Decal—Starting Instructions
	041939	7" Plastic-White-Diamond-Nylon Bearing	34	091249	Back Plate—Height Adjuster
	041863	7" Steel-White-Rib-Flange Bearing	35	457168	Bolt—3/8-16 x 7/8 Hx Hd Thd Forming
	042432	8" Plastic-White-Diamond-Nylon Bearing (3-Spoke)	36	150730	Bolt—Front Wheel
	041909	8" Plastic-White-Diamond-Nylon Bearing (4-Spoke)	37	152553	Washer, Flat—Height Adjuster
	041111	8" Steel-White-Rib-Flange Bearing	38	150201	Washer—5/16 Curved
7	040410	Wheel—16 x 1.75	39	150235	Wingnut—5/16-18
8	052209	Cable—Engine/Blade Control	40	150276	Key—#6 Woodruff
9	052217	Control—Throttle w/Cable	41	457499	Bolt—1/4-20 x 1/2 Hx Hd Thd Forming
10	071563	Handle—Lower	42	150318	Clamp—Cable
11	071076	Handle—Upper	43	150623	Screw—#10 x 5/8 Self-Tap
	071084	Handle—Upper with Cushion Grip*	44	157255	Bolt—Blade
12	381442	Clamp—Tinnerman	45	085019	Wheel Arm Assembly
13	156919	Washer—3/8 Lock H.D.	46	458687	Bolt—#10-24 x 1/2 Hx Hd
14	715524	Locknut 3/8-16 Jam	47	715011	Pin—#3 Hitch
15	114462	Plastic Tip—Height Adjuster	48	156877	Washer—3/8 Hardened
16	106005	Washer—Blade	49	380394	Bolt—3/8-16 x 3-3/4 Hx Hd
17	100396	Bar—Stabilizer	50	151928	Bolt—5/16-18 x 1-3/4 Curved Hd
18	101519	Baffle—Deck	51	152074	Stop—Rope
19	103424	Spacer—Wheel Sleeve	52	451492	Nut—3/8-16 TopLock Flange
20	104687	Bail—Engine/Blade Control	53	452318	Nut—#10-24 Nylon Insert
21	394619	Chute Deflector Assembly	54	156182	Washer, Plastic—Height Adjuster
22	110379	Tie—Cable	55	152371	Guide—Rope
23	715326	Bolt—3/8-16 x 1 Hx Hd	56	715037	Nut—1/4-20 Keps
24	156125	Bolt, Shoulder Height Adjuster	57	153874	Bolt—1/4-20 x 2-1/4 Hx Hd Gr 2
25	107086	Bracket—RH Handle	58	152405	Bolt—3/8-16 x 3/4 Carriage
26	107094	Bracket—LH Handle			
27	715417	Washer—3/8 SAE Flat			

• INDICATES OPTIONAL EQUIPMENT

• INDICATES OPTIONAL EQUIPMENT

- This parts list covers several different mower models; not all of the parts listed may be used on the particular model you are working with.
- When servicing use only **Genuine Factory Replacement Parts (OEM)** that are specifically designed for the particular model that you are working with.
- Parts are right or left hand as viewed from the operator's position.
- Model specifications are subject to change without prior notice.
- **Do not operate** the mower unless all parts are attached and in good working order.
- Lawn mower deck and/or other painted parts differing in color may be substituted without notice.