


# Model LS338



NOTE: The engine, shown here for reference only, may not resemble the engine on your equipment.

# Model LS338

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	781-0686	Log Tray Bracket	48.	712-0123	Hex Nut 5/16-24
3.	781-0682	Log Tray	49.	710-0409	Hex Cap Screw 5/16-24 x 1.75
4.	710-3097	Carriage Bolt 3/8-16 x 1.0	50.	710-1253	Hex Cap Screw 5/16-24 x 5.25
5.	719-0550	Wedge Assembly	51.	781-0098A	Front Support Bracket Coupling
6.	712-0239	Lock Nut 1/2-20	53.	736-0119	Lock Washer 5/16
7.	710-1018	Hex Cap Screw 1/2-20 x 2.75	54.	710-0237	Hex Cap Screw 5/16-24 x .625
8.	710-1806	Hex Screw 1/2-13 x 3.25	55.	719-0315	Shoulder Spacer
9.	781-0351	Adjustable Gib	56.	714-0114	Key
10.	712-0711	Hex Jam Nut 3/8-24	57.	712-0123	Hex Screw 5/16
11.	710-0459A	Hex Cap Screw 3/8-24 x 1.5	58.	718-0685	Flex Coupling
12.	781-0790	Back Plate	59.	781-0097	Rear Coupling Support Bracket
13.	736-0921	Lock Washer 1/2	60.	737-0264	Adapter 7/8-14
14.	736-0300	Flat Washer .406 ID x .875 OD	61.	718-0684	Pump (16 gmp)
15.	710-0514	Hex Screw 3/8-16 x 1.0	62.	726-0174	Hose Clamp
16.	781-0525	Dislodger	63.	727-0451	Suction Hose
20.	681-0129A	Beam Assembly	64.	710-0521	Hex Cap Screw 3/8-16 x 3.0
21.	714-0211	Cotter Pin	65.	712-0798	Hex Nut 3/8-16
22.	718-0313	Hydraulic Cylinder 31/33 Ton	66.	736-0169	Lock Washer 3/8
23.	711-1135	Clevis Pin	67.	781-0680A	Tube
24.	727-0471	Hydraulic Tube	68.	710-0411	Hex Cap Screw 3/8-16 x 4.0
25.	727-0443	Return Hose 3/4" ID x 44" Lg.	69.	681-0110	Support Beam Assembly
26.	781-0526	Hose Guard	70.	681-0006	Adjustable Jack Stand
27.	726-0132	Hose Clamp 5/8"	71.	710-0944	Hex Cap Screw 3/8-16 x 4.25
28.	737-0153	Return Elbow	72.	736-0262	Flat Washer .385 ID x .870 OD
29.	737-0264	90 Degree Solid Male Adapter	73.	713-0433	Chain
30.	737-0312	3/4" Hose Adapter	74.	750-0497	Spacer
31.	718-0481	Control Valve	75.	727-0311	Hitch Coupler
32.	737-0316	Filter Housing	76.	712-0375	Lock Nut 3/8-16
33.	723-0405	Oil Filter	77.	712-3008	Hex Jam Nut 3/8-16
34.	727-0502	High Pressure Hydraulic Hose	78.	721-0168	Bearing Seal
35.	781-0538	Hose Guard	79.	741-0987	Bearing Cone
36.	714-0470	Cotter Pin 1/8"	80.	634-0186	Wheel Assembly
37.	738-0805	Hinge Pin 1/2 x 4.8" Lg.	81.	634-0180	Rim Assembly
38.	726-0214	Push Cap	82.	736-0351	Flat Washer .76" ID x 1.5" OD
39.	732-0583	Compression Spring 4"	83.	712-0359	Slotted Nut 3/4-16
40.	736-0116	Flat Washer .635 ID x .93 OD	84.	714-0162	Cotter Pin 5/32" x 1-1/4" Lg.
41.	781-0690	Locking Rod	85.	734-0873	Hub Cap
42.	737-0348	Vented Dipstick	86.	681-0074	Light Bracket Assembly LH
43.	781-04002	Fender Assembly	87.	625-0009	Tail Light Assembly
44.	736-0371	Lock Washer 5/16	89.	781-0624	Light Bracket Assembly RH
45.	710-3038	Hex Screw	90.	712-3010	Hex Nut
46.	681-0178A	Frame Assembly 7.0 Gal	92.	712-3022	Lock Nut 1/2-13
47.	736-0119	Lock Washer 5/16			