



22" SIDE DISCHARGE ROTARY MOWER
 MODEL: FUDR22H
 Grass Catcher Model: GC 6AA - P/N 161018
 Repl. Bag: P/N 160457



Mowers Without Height Adjusters

22" SIDE DISCHARGE ROTARY MOWER
MODEL: FUDR22H
 Grass Catcher Model: GC 6AA - P/N 161018
 Repl. Bag: P/N 160457

Index No.	Part No.	Description	Index No.	Part No.	Description
1	013425	Deck 20"	21	144899	Decal-Starting Instructions
	016311	Deck 22"	22	150011	Bolt-Carriage 1/4-20 x 5/8
2	030031	Blade-20" Flat	23	150060	Wheel Bolt w/Hgt. Adj.*
	030049	Blade-22" Flat	24	150201	Washer-Curved 5/16
3		Wheel Assembly*	25	150235	Wingnut 5/16-18
	041012	6" Plastic - White - Diamond	26	150276	Woodruff Key #6
	041533	6 1/2" Plastic - White - Diamond	27	150318	Cable Clamp
	040246	7" Plastic-White-Diamond	28	155366	Screw-Sheet Metal #10 x 5/8
	041525	7" Plastic-White-Diamond	29	150730	Wheel Bolt w/o Hgt. Adj.*
	041046	7" Steel - White-Rib-Flange Bearing	30	162024	Bolt-Blade
	040857	8" Plastic-White-Diamond	31	153874	Bolt-1/4-20 x 2 1/4 Hex Head
	040865	8" Plastic-White-Diamond-Roller Bearing	32	151928	Bolt-Curved Head 5/16-18 x 1 3/4
	041111	8" Steel-White-Rib-Flange Bearing	33	152074	Rope Stop
4	051235	Control-Throttle w/Cable	34	152371	Rope Guide
5	051466	Cable-Engine Blade Control (Flag Type)	35	153650	Shoulder Bolt-Hgt. Adj.*
6	071563	Handle-Lower	36	428664	Back Plate-Height Adjuster R.H. Front L.H. Rear*
7	071076	Handle-Upper	37	428714	Back Plate-Height Adjuster L.H. Front R.H. Rear*
	071084	Handle-Upper Vinyl Grip	38	452318	Nut-#10-24 HX Nylon Insert
	072181	Handle-Upper Cushion Grip	39	457168	Bolt-3/8-16 x 7/8 Thread Forming
8	101519	Baffle 20/22" Rear or Front*	40	457499	Bolt-1/4-20 x 1/2 Thread Forming
9	104687	Bail-Engine/Blade Control	41	462093	Washer-Flat 1/4"
	109470	Bail-Engine/Blade Control Vinyl Grip	42	458687	Bolt-Hex Head #10-24 x 1/2
10	106336	Washer-Blade Adapter	43	714170	Decal-Model Number
11	106914	Clip-Trailing Shield	44	715011	Hairpin Cotter
12	107086	Handle Bracket-Right Hand	45	715037	Nut-Keps 1/4-20
13	107094	Handle Bracket-Left Hand	46	715045	Bolt-Hex Head 1/4-20 x 3/4*
14	391706	Chute Deflector Assembly	47	451492	Locknut 3/8-16 Top TopLock Flange
15	110379	Cable Tie	48	715201	Bolt-Hex 3/8-16 x 3/4 w/o Hgt. Adj.
16	111609	Trailing Shield-20/22" w/o Hgt. Adj.	49	715607	Washer-Belleville
	111617	Trailing Shield-20/22" w/Hgt. Adj.	50	715417	Washer 3/8 SAE*
17	111559	Plastic Tip-Setting Lever*	51	715508	Locknut 1/4-20 Top
18	133231	Blade Adapter	52	776500	Setting Lever-Height Adjuster*
19	144063	Decal-Danger	53	777862	Wheel Lever-Height Adjuster*
20	001206	Decal-Blade Warning			

• INDICATES OPTIONAL EQUIPMENT

• INDICATES OPTIONAL EQUIPMENT

NOTE: This parts list covers several different mower models. Not all of the Parts listed may be used on your particular mower.
 When servicing use only genuine factory replacement parts that are specifically for your particular model.
NOTE: Parts are right or left hand as viewed from the operator position.
 Specifications subject to change without prior notice.