


Model Series V/GB2X



Model Series V/GB2X

Ref No.	Part Number	Description
1	787-01871	Deck, 21"
	787-01872	Deck, 21" (Kolher)
2	941-00019	Bearing Assembly
3	710-04995	Screw, 5/16-14 x .750
4	712-04222	Nut, Sq., 1/4-20
5	749-04608A	Lower Handle
6	710-04998	Carriage Screw, 5/16-18
7	710-0654A	Screw, 3/8-16 x 1.00
8	987-02527	Blade Adapter
	687-02528	Blade Adapter (Kohler)
9	942-0741A	Mulching Blade
10	736-0524B	Blade Bell Support
11	710-1044	Screw, 3/8-24 x 1.50
12	731-07203	Trailing Shield
13	732-04675A	Transmission Wire
14	747-05226	Grass Catcher Frame
15	764-04082A	Grass Bag
	764-04077A	Grass Bag (Kohler)
16	631-04369	Rear Discharge Door Assembly
17	732-04673	Torsion Spring - RH
18	732-04674	Torsion Spring - LH
19	720-04131A	Adjustment Lever Knob
20	710-05073	Screw, 1/4-20 x .500
21	732-04704	Compression Spring
22	731-07797	Front Cover
23	787-01793	Front Axle Clip
24	712-04064	Nut, Flange Lock, 1/4-20
25	720-04124	Wing Knob
	720-04122	Wing Knob (Kohler)
26	911-04150	Front Axle Assembly
27	931-04535	Engine Baffle
28	911-04142	Rear Axle Assembly
29	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
30	710-04531	Screw, 1/4-20 x .390
31	918-04881A	Transmission Assembly
32	712-04217	Flange Lock Nut, 3/8-16
33	734-2042A	Front Wheel
34	634-04630	Rear Wheel

Ref No.	Part Number	Description
35	715-04099	Dowel Pin
36	753-06060	Control Lever Assembly
37	749-04679	Upper Handle
38	710-0895	Screw, 1/4-15 x .750
39	720-0279	Knob
40	725-0157	Cable Tie
41	710-1205	Rope Guide
42	946-04655A	Drive Cable
43	746-04479	Control Cable
	946-1130	Control Cable (Kohler)
44	747-05209A	Blade Control
45	720-04127A	Wing Nut
	720-04123A	Wing Nut (Kohler)
46	738-04419A	Sldr. Screw, .375 x .126 x 1/4-20
47	731-07487	Water Nozzle
48	731-07240	Wheel Dust Cover
49	731-07355	Spring Body
50	738-04278	Scr., Shldr., 1/4-20 x .50
51	731-07789	Lower Tray
52	954-04260	V-Belt
53	747-05183	Pivot Rod
54	710-04744†	Screw, #12-16 x 1.00
55	931-04471†	Engine Shroud, Oyster Gray
	631-04562†	Engine Shroud, Black
56	731-07486	Side Discharge Chute
	731-07131	Side Discharge Chute (Kohler)
57	987-02516	Mulch Plug (Incl. 58-60)
58	732-1014	Torsion Spring
59	747-0710A	Hinge Pin
60	787-01779	Chute Deflector Bracket
61	710-05073	Screw, 1/4-20 x .500
62	725-04329†	Battery Charger
63	710-0136†	Screw, 1/4-20 x 1.75
64	710-0276†	Bolt, Carr., 5/16-18 x 1.00
65	912-0429†	Nut, Hexlk, 5/16-18
66	925-0201†	Key
67	725-04903†	Battery
68	738-04431†	Scr., Sldr., 5/16-14 x .972
69	725-05112†	Key Switch

† If Equipped

Continued on next page

Model V/GB2X

Ref No.	Part Number	Description
70	726-0201†	Speed Nut
71	731-07135†	Battery Housing
72	731-07154†	Battery Housing Top
73	731-07155†	Electric Start Housing
74	735-04213A†	Lid Seal
75	736-0242†	Washer, Bell, .340 x .872 x .080
76	731-07001	Hubcap, Grey
	731-07049	Hubcap, Yellow
77	731-07875	Hubcap, 11", Grey
	731-07876	Hubcap, 11", Yellow
78	921-04041	Water Nozzle Adapter
—	725-05015†	Wire Harness (Not Shown)