


## Parts List



**Curved Shaft,  
2-Cycle Trimmer**

**Model  
41AD-Y28-G000**



**IMPORTANT:** Read safety rules and instructions carefully before operating equipment.

**Warning:** This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator. In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester is installed on this unit. A replacement spark arrester for the muffler is available through your nearest engine authorized service dealer or contact the customer service department: 1-800-345-8746.


**MTD SOUTHWEST INC 550 N. 54TH STREET, CHANDLER, ARIZONA 85226-2434**

PRINTED IN U.S.A.

(10/01)

# SECTION 9: PARTS LIST FOR MODEL 41AD-Y28-G000

## Engine




## MODEL 41AD-Y28-G000: Engine

Ref. No.	Part No.	ENGINE Part Description
1	182059	Air Cleaner/Muffler Cover Assembly (includes 2 & 37)
2	180350B	Air Cleaner Filter
3	180351	Carburetor Mounting Screw Assembly
4	180226	Wavy Washer
5	182201	Choke Lever Assembly (includes 6)
6	182202	Choke Knob and Screw
7	182203	Choke Lever and Plate (includes 5)
8	182532	Carburetor Assembly W/Limiter Caps (includes 9 & 21)
9	610675	Carburetor Gasket
10	181860	Carb Mount Screw
11	683974B	Primer and Hose Assembly
12	182063	Carb Mount Assembly (includes 10, 13, 15)
13	684451	Reed Assembly
14	181866	Power Shaft Assembly
15	612115	Carburetor Mount Gasket
16	181865	Crank Case Service Assembly (includes 10, 14 & 24)
17	612134	Rear Mounting Pad
18	181908	Fuel Tank Assembly (includes 19-21)
19	160187	Fuel Cap Assembly
20	181168	Fuel Return Line
21	682039	Fuel Line Assembly
22	145308	Front Mounting Pad
23	153520	Shroud Assembly
24	181861	Shroud Screw
25	182064	Shroud Extension and Stand
26	181867	Flywheel Assembly
27	610303	Nut
28	181597	Recoil Pulley Assembly
29	613102	Recoil Spring
30	611061	Rope Guide

Ref. No.	Part No.	ENGINE Part Description
31	180930	Pulley Retainer Assembly
32A	182673	Positive Switch
32B	182441	Momentary Switch
33	181079	Pull Handle
34	613103	Rope
35	182721	Starter Housing Assembly (includes 28-31, 33-34, 36, 37)
36	181862	Housing Screw
37	181345	Cover Screw
38	153597	Upper Clamp Assembly
39A	182879	Governed Module Assembly
39B	791-00056	Pulse Module Assembly
40	147095	Spark Plug
41	182065	Exhaust Gasket
42	182066	Muffler Assembly (includes 41 & 43)
43	147575	Muffler Mounting Bolt Assembly
44	181622	Cylinder Assembly (includes 43, 46 & 47)
45	684449	Piston and Rod Assembly
46	610674	Cylinder Gasket
47	182723	Cylinder Bolt
48	611063	Male Tab (for use with 32A and 39B only)
49	182747	Spark Arrestor
50	181936	Lead Wires
*	182067	Engine Gasket Kit
*	180602	O.E.M. Carburetor Repair Kit (Walbro)
*	180090	O.E.M. Carburetor Repair Kit (Zama)
*	181069	Gasket Diaphragm Repair Kit (Walbro)
*	180091	Gasket Diaphragm Repair Kit (Zama)
*	180530	Piston Ring
*	181863	Short Block Assembly (includes 10, 14, 16, 24, 40, 44-47)
*	181501	Starter Housing Screw Set
*	610309	Crankcase Seal
		*Items Not Shown

# MODEL 41AD-Y28-G000



Boom and D-Handle

## MODEL 41AD-Y28-G000: Boom and D-Handle

Ref. No.	Part No.	BOOM AND D-HANDLE Part Description
1	791-00059	Throttle Housing and Trigger Assembly (includes 2 & 3)
2	610314	Throttle Trigger Spring
3	181807	Throttle Trigger
4	182068	Throttle Cable Assembly
5	153064	D-Handle Assembly (includes 6)
6	181587	D-Handle Hardware
7	181893	Drive Housing
8	153597	Lower Clamp Assembly
9	182839	Flexshaft
10	180531	Shield Mounting Screw Assembly
11	181784	Bushing Housing Assembly with Spool Shaft
12	145569	Anti-Rotation Screw
13	683274	Shield & Blade Assembly (includes 14)
14	682061	Blade Assembly
15	153619	Outer Spool & Eyelet (includes 16)
16	610660	Retainer
17	610317B	Spring
18	610318	Inner Reel
19	153066B	Bump Head™ Assembly
<b>Optional Accessories</b>		
*	610375	Replacement Line
*	153577B	Reel and Line Assembly
*	180897B	Bump Head™ Assembly (includes 15-19)
*	682075B	Shoulder Strap
		*Items Not Shown