


TYPE 1




Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016360	Screw (brg hsg/blwr)	Not Shown		
2.	530015518	Screw-Shaft Alignment			
3.	530094581	Assy-Bearing Hsg. (incl. # 2,4,5)			
4.	530092227	Washer-Lock (star)		530088053	Manual
5.	534828400	Bolt		530095894	Hanger-Attachment
6.	530095891	Blower-Scroll (upper)		530056340	Decal-Impeller Hsg.
7.	530055123	Impeller			
8.	530095892	Blower-Scroll (lower)			
9.	530016273	Screw			
10.	530095884	Flexshaft-Split Boom			
11.	530095990	Assy-Lower Driveshaft			

✓ = NEW PART NUMBER FOR THIS IPL


★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

TYPE 2



WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530096026	Clamp-Right			
2.	530015814	Screw			
3.	530096042	Hsg.-Blower (upper)			
4.	530016389	Washer			
5.	530055123	Impeller			
6.	530095893	Arbor-Impeller			
7.	530095892	Hsg.-Blower (lower)			
8.	530016273	Screw			
9.	530016179	Screw			
10.	530096025	Clamp-Left			
11.	530071609	Assy-Lower Driveshaft (incl. flex)			
			Not Shown		
			↗ 545133455	Manual	
			530095894	Hanger-Attachment	
			530056340	Decal-Impeller Hsg.	

↗ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)