




Ref #	Part Number	Qty	Description
1	530089210		Fan Cover - Type 1
2	530089366		Screw - Type 1
3			Front Fan Case
	530089360		Type 1
	530089434		Type 2
4	530089362		Cap-Type 1
5	530089368		Isolator
6	530089319		Bolt
7	530089209		Fan
8	530089367		Screw
9			Cover
	530089213		Type 1
	530089435		Type 2
10	530089361	PP442 Gas Blower Fan, Frame & Shoulder Strap	Real Fan Case
11	530089365		Screw
12	530089316		Nut
13	530089314		Washer
14			Shoulder Band
	530089204		Type 1
	530089430		Type 2
15	530089315		Screw
16	530089203		Bracket
17	530089326		Nut
18	530089201		Pad
19	530089317		Bolt
20	530089202		Clamp
21			Frame
	530089200		Type 1
	530089429		Type 2
22	530089369		Washer
23	530089359		Screw
24	530089358		Bracket - Type 1
25	530089318		Bolt - Type 1
26	530089230		Wire Band
27	530089324		Nut
28	530089364		Screw




Ref #	Part Number	Qty	Description
1	920372163		Clamp
2	920372109		Clamp
3	590712077		Joint
4	920592217		Tube
5	411S0500		Washer
6	490192063		Filter
7	130422058		Weight
8			Tank Cap
	510492067		Type 1
	510482073		Type 2
9	140692056		Breather
10			Fuel Tank
	510012232	PP442 Gas Blow Pipe 4 of 10	Type 1
	510012256	Fuel Tank & Carburetor	Type 2
11	671B2550		O-Ring
12	110112213		Filter Case
13	110132127		Element
14	593662008		Grate
15	110122269		Cap
16	241B0412		Screw
17	110132111		Element
18	410772062		Adapter
19	920092310		Screw
20	110092781		Gasket
21			Screw
	920092298		Type 1
	920092209		Type 2
22	140242235		Cover
23	110092834		Gasket
24	140432051		Filter
25	920332068		Ring - Snap
26	160412193		Shaft
27	210832003		Adjuster
28	921442311		Spring
29			Valve - Throttle
	160252148		Type 1
	160252185		Type 2
30	920092140		Screw
31	920152097		Nut
32	110092781		Gasket
33	160732127		Insulator
34	214B0516		Screw
35	410772061		Adapter
36	110602061		Gasket
37	110602300		Gasket
38			Screw
	920092083		Type 1
	920092379		Type 2
39			Cover
	140242236		Type 1
	140902027		Type 2
40	490432069		Plunger
41			Primer Base
	161602094		Type 1
	161602104		Type 2
42			Diaphragm

Ref #	Part Number	Qty	Description
	430282072		Type 1
	430282081		Type 2
43			Gasket
	110092835		Type 1
	110602123		Type 2
44	920092084		Screw
45	233B0520		Screw
46	920812308		Spring
47	160302078		Valve - Float
48	920432094		Pin
49	160552065		Arm - Float
50	921442217		Spring-Type 1
51	160092115	PP442 Gas Flowmeter	Needle - Type 1
52		Fuel Tank & Carburetor	Screw
	920092083		Type 1
	160212051		Type 2
53	160092135		Needle - Type 1
54	921442181		Spring
55	920092140		Screw
56	131832303		Plate
57	133102011		Shaft Assy
58	161262166		Valve - Choke
59	921402057		Ball
60	921442219		Spring
61	430282071		Diaphragm Pump
62	490192097		Filter Ass'y. (Incl. 1 - 7)
63	530089438		Clamp
64	530089439		Tube
65	530089440		Filter
66	530089441		Seal
67	920552147		O-Ring - Type 2



Ref #	Part Number	Qty	Description
1	921502180		Bolt
2	490702577		Muffler
3	110092873		Gasket
4	180772093		Spark Arrester
5	921502131		Bolt
6	920222385		Washer
7	490892370		Shroud
8	920092285		Screw
9	490892298		Shroud
10	211692051		Terminal
11	211302056		Cap
12	920702066		Spark Plug
13	490062051	PP442 Gas Blower	Boot
14	920382078	Interior Power Unit	Key
15	210502181		Flywheel
16	920222147		Washer
17	314R1000		Nut
18	180R0520		Bolt
19	920592233		Tube
20	920712077		Grommet
21			Ignition Coil Ass'y.
	211712165		Type 1
	211712201		Type 2
22	211192134		Igniter-Type 1 Only
23	214B0408		Screw-Type 1 Only
24			Lead Wire
	260112263		Type 1
	260112321		Type 2
25	140022240		Crankcase - Drive Side
26	223B0630		Screw
27	751Q0600		Gasket
28	214B0608		Screw
29	920492076		Oil Seal
30	920452005		Bearing
31	491196090		Crankshaft Assy
32			Shim
	920252134		T=0.10
	920252135		T=0.20
	920252136		T=0.40
	920252127		T=0.60
33	130332005		Needle Bearing
34	920332058		Snap Ring
35	130022065		Piston Pin
36	130012121		Piston
37	130086049		Piston Ring Set
38	110092854		Gasket
39	110052114		Cylinder
40	920022150		Bolt
41	920702066		Spark Plug
42	110092521		Gasket
43	551A0610		Pin
44	920332010		Ring
45	490802155		Starter Pulley
46	921442046		Spring-Return
47	131652070		Pawl
48	410B0800		Washer

Ref #	Part Number	Qty	Description
49	315B0800		Nut
50	922002019		Washer
51	920092218		Screw
52	591012085		Recoil Starter
53	591062117		Rope
54	921442038		Spring - Recoil
55	242B0416		Screw
56	320992210		Starter Case
57	460752067		Grip
58	131692386		Plate
59	130702064		Rope Guide
60			Cable-Throttle
	540122535	PP442 Gas Blow	Page 8 of 10
	540122562	Interior Power Unit	
61			Type 1
	610022053		Type 2
	920092354		Screw
62	312B0600		Type 1
63	110462086		Type 2
64	490882380		Nut
65	140022239		Bracket
			Starter Ass'y. (Incl. 50-54 & 56-59)
			Crankcase - Starter Side



Ref #	Part Number	Qty	Description
1	530089363		Elbow Pipe Ass'y. (Incl. 2 & 3)
2	530089212		O-Ring
3	530089211		Elbow Pipe
4	530089229		Hose Band
5	530089436		Wire Clamp
6	530089225		Flexible Pipe
7	530089386		Base Pipe
8			Stop Switch
	530089384		Type 1
	530089432		Type 2
9	530089442		Throttle Lever Ass'y. - Type 2
10	530089431		Lever Ass'y.
11	530089443	PP442 Gas Pipe, 10 of 10	Wire Bolt
12	530089444	Pipes, Tubes & Throttle Ass'	Washer
13	530089387		Middle Pipe
14	530089388		Bend Pipe
15			Tube
	530089385		Type 1
	530089433		Type 2
16	530089230		Wire Band
17	530089380		Throttle Lever
18	530089372		Stay
19	530089383		Washer
20	530089382		Lockwasher
21	530089381		Nut
22	530089379		Screw
23	530089375		Bolt
24	530089373		Spacer
25	530089374		O-Ring
26	530089371		Stay
27	530089378		Washer
28	530089377		Lockwasher
29	530089376		Nut
30	530089370		Throttle Lever Ass'y. - Type 1 (Incl.25-29)