



**⚠ WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530054942	Assy-Throttle cable	20.	530016224	Screw
2.	530015805	Screw-alignment	21.	530095814	Non-Blade Dust cup
3.	530015886	Screw	22.	530052285	Limiters-Line
4.	530054837	Throttle Hsg.-Right	23.	530015805	Screw
5.	530071553	Kit-Left Throttle Hsg.	24.	530015820	Bolt
6.	530054943	Assy-Front wire	25.	530016152	Wingnut
7.	530055724	Assy- Front Wire (upper)	26.	530069779	Kit-Shield Ass'y. (Incl. 22-25)
8.	530069572	Kit-Switch	27.	952711581	Accy.- Cutting Head (Incl. 28-31)
9.	530055699	Handle	28.	530095772	Assy. - Hub/Arbor (3/8lh , 2x)
10.	530015820	Bolt	29.	530053241	Spring - Return
11.	530015886	Screw	30.	530401957	Retainer - Spool
12.	530054940	Trigger-Throttle	31.	952711580	Accy.-Wound Spool
13.	530095963	Shaft-Flex	Not Shown		
14.	530055355	Assy-Driveshaft			
15.	530088416	Clamp-Assist Handle			
16.	530016152	Wingnut			
17.	530095812	Bracket - Shield	530164435	Operator Manual	
18.	530071584	Assy.-Gearbox non blade	530055350	Decal-Shaft Warning	
19.	530016014	Screw	530057369	Decal-Start Instructions	

**WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530047721	Bulb-Purge	24.	530055492	Isolator-Tank	48.	530012427	Coupling-Drive
2.	530071717	Kit-Choke Lever	25.	530054941	Ret.-Tank	49.	530010960	Assy-Conn. Rod
3.	530015843	Screw-Tank	26.	530054834	Handle-Starter	50.	530015162	Ret.-Piston pin
4.	530049386	Cap-Fuel w/ret.	27.	530071400	Kit-Rope	51.	530025875	Ring-Piston
5.	530095646	Assy-Fuel pickup	28.	530032103	Bearing-Inner	52.	530069277	Kit-Piston (Incl. 50,51)
6.	530071404	Kit-Fuel line	29.	530015787	Retainer	53.	530071401	Gasket-Cylinder(kit)
7.	530069216	Kit-Fuel/Purge line	30.	530019158	Seal	54.	530057238	Assy-Leadwire
8.	530015775	Screw	31.	530032102	Bearing-Outer	55.	530069310	Kit-Muffler
9.	530054935	Cover-Air box	32.	530015789	Ret.-Crankshaft	56.	530058957	Shield
10.	530054946	Filter-Air	33.	530012430	Assy-Crankshaft	57.	530036409	Spring-Muffler
11.	530015849	Screw-Carb.	34.	530012514	Assy-Crankcase (Incl. 28-31)	58.	530071581	Kit-Cylinder
12.	530054934	Box-Air	35.	530071686	Assy-C'case/C'shaft (Incl. 32,33,34)	59.	952030249	Plug-Spark(RCJ-6Y)
13.	530071636	Assy-Carb(WT627)	36.	530071402	Kit-Flywheel Assy.	60.	530001624	Bolt-Cyl. 1/4-20"
(Note: Repair kits are not available for this carburetor)			37.	530016030	Washer	61.	530039218	Module-Ignition
14.	530071401	Gasket-Carb.(kit)	38.	530055620	Spacer	62.	530016357	Screw-Module
15.	530055317	Assy-Fuel Tank	39.	530015775	Screw-Baffle	63.	530071401	Kit-Gasket (Incl. 14,19, 53)
16.	530015771	Screw-Crankcase	40.	530054939	Plate-Baffle			
17.	530015952	Screw-Shroud	41.	530016391	Screw-Rope			
18.	530056044	Shroud	42.	530071399	Kit-Pulley(incl.41)			
19.	530071401	O-ring-Shroud (kit)	43.	530042086	Spring-Starter			
20.	530027593	Valve-Reed	44.	530019182	Grommet			
21.	530054596	Stop-Reed	45.	530015810	Screw-F/hsg.			
22.	530016064	Screw-Reed stop	46.	530055248	Assy.-Fan Housing			
23.	530015875	Screw-Retainer	47.	530016030	Washer			

✓ = NEW PART NUMBER FOR THIS IPL

\* = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)